OC Subsection: [F-3681] New OC Subsection: 06 Driving / Wipers and Washers

Description:

UC "Setting the mode of wipers"

Preconditions:

- 1. The vehicle is power on
- 2. The driver is sitting in the driver's seat

Main Scenario:

1. The driver activates the wipers in one of the following ways, using **in_10. Front buttons steering wheel** or on the **in_2. SWP Android**:

- 1.1. There are 5 wiper states:
 - Off wipers and washer are off
 - Auto works based on sensor data
 - 1 low speed of wipers. The wipers operate until the user turns them off.
 - 2 average speed of wipers. The wipers operate until the user turns them off.
 - 3 fast speed of wipers. The wipers operate until the user turns them off.

1.2. **in_10. Front buttons steering wheel** control:

- Single press (second gear contact)
 - If the wipers are turned off, then press once (second gear contact) to turn on 1 speed.
 - If the wipers were turned on at any speed (1-2), then the next speed is turned on.
 - If the third speed is turned on, after press the button wipers turns off
- If the Auto mode was active and any of the above actions is activated, Auto mode is temporarily disabled. After X seconds Auto mode is activated.
- Quick Half Press (first gear contact):
 - One sweep of the wipers
 - After a single wipe, the wipers return to their previous state
- Half press and hold the button (first gear contact):
 - While the button is held down, washer + wiper works ((min 3 swipes, TBD), timeout 15 sec, TBD)
 - If the wipers are active and one of the speed levels is applied (including the use of speed modes with the Auto mode), then cleaning occurs using the current speed mode
 - If the wipers are not active (including combinations of Auto mode + off), then the default speed of the wipers is set level 2

After the driver releases the button after \mathbf{X} sec, there will be a single wipers swipe (for the final cleaning of the glass from drops).

• When the driver releases the button, the wipers return to the previously set mode or are turned

off.

- Press repeatedly (3 or more times second gear contact) causes "Rush" mode (3 speed)
 - Exit the mode single press (second gear contact) on the button
 - If the Auto mode was active, it is temporarily disabled. After X seconds Auto mode is activated again
- Long press (second gear contact) button in_10. Front buttons steering wheel to call the wiper menu on out 2. SWP Android

1.3. out_2. SWP Android control:

- Wiper operating mode (1 3 speed)
- Turn off the wipers
- Front washer (water flow from front washer nozzles)
- Auto mode on/off (wipers operate in Auto mode by default)
- Service mode (wipers vertically upward to replace rubber bands/brushes)
- Rear washer

Postconditions:

- The driver has set their preferred mode for the wipers, including speed and auto mode.
- The driver profile stores information about Auto mode:
 - If Auto mode is turned on, then the next time when turn on the car, Auto mode will be active
 - If Auto mode is turned off, then the next time when turn on the car, Auto mode and other Wipers and washer settings will be inactive

Priority: Normal

Type: Use Case CF

Document

Caption: operational_concept.Profile - 383201 Profiles settings

Overall estimation:

Requirement type: Profile

Type: Profile